

U72 Option Switch Settings (Pulse/MDB/RS232 104U)

Supported bill RUB 10, 50, 100, 200, 500, 1000 6 Bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject RUB 10	ON											
★ Accept RUB 10	OFF											
★ Reject RUB 50		ON										
★ Accept RUB 50		OFF										
★ Reject RUB 100			ON									
★ Accept RUB 100			OFF									
★ Reject RUB 200				ON								
★ Accept RUB 200				OFF								
★ Reject RUB 500					ON							
★ Accept RUB 500					OFF							
★ Reject RUB 1000						ON						
★ Accept RUB 1000						OFF						
★ Harness Disable							ON					
★ Harness Enable							OFF					
★ Inhibit Active HIGH								ON				
★ Inhibit Active LOW								OFF				
★ 1 pulse / Ruble 10									OFF	OFF		
2 pulses / Ruble 10									ON	OFF		
5 pulses / Ruble 10									OFF	ON		
10 pulses / Ruble 10									ON	ON		
★ Pulse Speed	50ms on / 50ms off										OFF	OFF
	60ms on / 300ms off										ON	OFF
	30ms on / 50ms off										OFF	ON
	150ms on / 150ms off										ON	ON

★Manufacture setting

Note (1) Please reset the bill acceptor after any changes on Dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

U72 RUB6(Pulse/MDB/RS232 104U)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal High	ON			
	Credit-Pulse Normal Low	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	Reserved			OFF	OFF
	Reserved			OFF	ON
	Reserved			ON	OFF
	Reserved			ON	ON

★Manufacture setting

DIP SWITCHES SETTING : 2(RS232 104U)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	MDB			OFF	OFF
	RS232 104U			OFF	ON
	Reserved			ON	OFF
	Reserved			ON	ON

★Manufacture setting

DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	MDB			OFF	OFF
	RS232 104U			OFF	ON
	Reserved			ON	OFF
	Reserved			ON	ON

★Manufacture setting

Note :(1) Please reset the bill acceptor after any changes on Dip switch.

(2) Please open the panel of front, and can see the DIP switch.

Currency Assign Data

Interface Bill value	Pulse	MDB	RS232 104U
BV1	RUB 10	RUB 10	RUB 10
BV2	RUB 50	RUB 50	RUB 50
BV3	RUB 100	RUB 100	RUB 100
BV4	RUB 200	RUB 200	RUB 200
BV5	RUB 500	RUB 500	RUB 500
BV6	RUB 1000	RUB 1000	RUB 1000