



## TP21/P5 Protocol for RS232 104U / Pulse

UYU7 Support bill 20 、 50 、 100 、 200 、 500 、 1000 、 2000 (Uruguay)

### DIP SW SETTING : 1

FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / UYU 10	OFF	OFF	OFF							
	2 Pulse / UYU 10	OFF	OFF	ON							
	3 Pulse / UYU 10	OFF	ON	OFF							
	4 Pulse / UYU 10	OFF	ON	ON							
	5 Pulse / UYU 10	ON	OFF	OFF							
	10 Pulse / UYU 10	ON	OFF	ON							
	20 Pulse / UYU 10	ON	ON	OFF							
	100 Pulse / UYU 10	ON	ON	ON							
	Fast Output Pulse	Lo=50ms Hi=100ms			ON						
★	Slow Output Pulse	Lo=50ms Hi=300ms			OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
★	Accept UYU 20 & 50						ON				
	Reject UYU 20 & 50						OFF				
★	Accept UYU 100							ON			
	Reject UYU 100							OFF			
★	Accept UYU 200								ON		
	Reject UYU 200								OFF		
★	Accept UYU 500									ON	
	Reject UYU 500									OFF	
★	Accept UYU 1000 & 2000										ON
	Reject UYU 1000 & 2000										OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch

### DIP SW SETTING : 2

FUNCTION		SW1	SW2	SW3	SW4
★	Pulse Normal High (NO)	ON			
	Pulse Normal Low (NC)	OFF			
★	Pulse Protocol		ON		
	RS232 Protocol		OFF		
	Straight			ON	
★	Turn Over			OFF	
	Reserved				ON
★	Reserved				OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch