



TP21/P5 Protocol for RS232 004 / Pulse

EUR4 Support bill 5 、 10 、 20 、 50 (Euro)

DIP SW SETTING : 1

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / EUR 5	OFF	OFF	OFF							
	2 Pulse / EUR 5	OFF	OFF	ON							
	3 Pulse / EUR 5	OFF	ON	OFF							
	4 Pulse / EUR 5	OFF	ON	ON							
	5 Pulse / EUR 5	ON	OFF	OFF							
	10 Pulse / EUR 5	ON	OFF	ON							
	20 Pulse / EUR 5	ON	ON	OFF							
	100 Pulse / EUR 5	ON	ON	ON							
	Fast Output Pulse	Lo=50ms Hi=100ms			ON						
★	Slow Output Pulse	Lo=50ms Hi=300ms			OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
★	Accept EUR 5						ON				
	Reject EUR 5						OFF				
★	Accept EUR 10							ON			
	Reject EUR 10							OFF			
★	Accept EUR 20								ON		
	Reject EUR 20								OFF		
★	Accept EUR 50									ON	
	Reject EUR 50									OFF	
★	Reserved										ON
	Reserved										OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch.

DIP SW SETTING : 2

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High (NO)	ON			
	Pulse Normal Low (NC)	OFF			
★	Pulse Protocol		ON		
	RS232 Protocol		OFF		
	Straight			ON	
★	Turn Over			OFF	
	Reserved				ON
★	Reserved				OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch.