



TP77P3B/P5 Protocol for RS232 104U / Pulse

TRY6 Support bill 5、10、20、50、100、200 (Turkey)

DIP SW SETTING : 1

| FUNCTION | | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW9 | SW10 |
|-----------------------------|---------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|
| ★ Normal Pulse | Special Pulse | | | | | | | | | | |
| 1 Pulse / TRY 5 | 1 Pulse / TRY 10 | OFF | OFF | OFF | | | | | | | |
| 2 Pulse / TRY 5 | 2 Pulse / TRY 10 | OFF | OFF | ON | | | | | | | |
| 3 Pulse / TRY 5 | 3 Pulse / TRY 10 | OFF | ON | OFF | | | | | | | |
| 4 Pulse / TRY 5 | 4 Pulse / TRY 10 | OFF | ON | ON | | | | | | | |
| 5 Pulse / TRY 5 | 5 Pulse / TRY 10 | ON | OFF | OFF | | | | | | | |
| 10 Pulse / TRY 5 | 10 Pulse / TRY 10 | ON | OFF | ON | | | | | | | |
| 20 Pulse / TRY 5 | 20 Pulse / TRY 10 | ON | ON | OFF | | | | | | | |
| 100 Pulse / TRY 5 | 100 Pulse / TRY 10 | ON | ON | ON | | | | | | | |
| Fast Output Pulse | Lo=50ms Hi=100ms | | | | ON | | | | | | |
| ★ Slow Output Pulse | Lo=50ms Hi=300ms | | | | OFF | | | | | | |
| ★ Inhibit level Active Low | | | | | | ON | | | | | |
| ★ Inhibit level Active High | | | | | | OFF | | | | | |
| ★ Accept TRY 5 (Note 2) | | | | | | | ON | | | | |
| ★ Reject TRY 5 (Note 2) | | | | | | | OFF | | | | |
| ★ Accept TRY 10 | | | | | | | | ON | | | |
| ★ Reject TRY 10 | | | | | | | | OFF | | | |
| ★ Accept TRY 20 | | | | | | | | | ON | | |
| ★ Reject TRY 20 | | | | | | | | | OFF | | |
| ★ Accept TRY 50 | | | | | | | | | | ON | |
| ★ Reject TRY 50 | | | | | | | | | | OFF | |
| ★ Accept TRY 100 & 200 | | | | | | | | | | | ON |
| ★ Reject TRY 100 & 200 | | | | | | | | | | | OFF |

★ Default setting

Note: (1) Please reset the bill acceptor after any changes on Dip switch.
(2) SW6

DIP SW SETTING : 2

| FUNCTION | SW1 | SW2 | SW3 | SW4 |
|--------------------------|-----|-----|-----|-----|
| ★ Pulse Normal High (NO) | ON | | | |
| Pulse Normal Low (NC) | OFF | | | |
| ★ Pulse Protocol | | ON | | |
| RS232 Protocol | | OFF | | |
| Straight | | | ON | |
| ★ Turn Over | | | OFF | |
| Special Pulse | | | | ON |
| ★ Normal Pulse | | | | OFF |

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch

Set ON, Accept 5 TRY (Normal Pulse)

| Pulse |
|--------------------|
| TRY 5 = 1 pulse |
| TRY 10 = 2 pulse |
| TRY 20 = 4 pulse |
| TRY 50 = 10 pulse |
| TRY 100 = 20 pulse |
| TRY 200 = 40 pulse |

Set OFF, Reject 5 TRY (Special Pulse)

| Pulse |
|--------------------|
| TRY 10 = 1 pulse |
| TRY 20 = 2 pulse |
| TRY 50 = 5 pulse |
| TRY 100 = 10 pulse |
| TRY 200 = 20 pulse |