

U72 Option Switch Settings (Pulse/MDB/RS232 104U)

Supported bill NAD 10, 20, 50, 100, 200 5 Bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject NAD 10	ON											
★ Accept NAD 10	OFF											
★ Reject NAD 20 & 50		ON										
★ Accept NAD 20 & 50		OFF										
★ Reject NAD 100 & 200			ON									
★ Accept NAD 100 & 200			OFF									
★ High Acceptance				ON								
★ High Security				OFF								
★ Enable, if fishing, BA doesn't work anymore					ON							
★ Disable, if fishing, BA Stop 3 minute.					OFF							
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★ Harness Disable							ON					
★ Harness Enable							OFF					
★ Inhibit Active HIGH								ON				
★ Inhibit Active LOW								OFF				
★ Power On Stacker									ON			
★ Power On Reject									OFF			
★ Slow Output Pulse	Lo 50 ms									ON		
	Hi 300 ms											
★ Fast Output Pulse	Lo 50 ms									OFF		
	Hi 100 ms											
★ Reserved											ON	
★ Reserved											OFF	
★ Reserved												ON
★ Reserved												OFF

★Manufacture setting

Note : Please reset the bill acceptor after any changes on Dip switch.

U72 NAD5(Pulse/MDB/RS232 104U)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal High	ON			
	Credit-Pulse Normal Low	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / NAD 10			OFF	OFF
	2 pulse / NAD 10			OFF	ON
	4 pulse / NAD 10			ON	OFF
	20 pulse / NAD 10			ON	ON

★Manufacture setting

DIP SWITCHES SETTING : 2(RS232 104U)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB			OFF	OFF
★	RS232 104U			OFF	ON
	Reserved			ON	OFF
	Reserved			ON	ON

★Manufacture setting

DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB			OFF	OFF
	RS232 104U			OFF	ON
	Reserved			ON	OFF
	Reserved			ON	ON

★Manufacture setting

Note :(1) Please reset the bill acceptor after any changes on Dip switch.

(2) Please open the panel of front, and can see the DIP switch.

Currency Assign Data

Interface / Bill value	Pulse	MDB	RS232 104U
BV1	NAD 10	NAD 10	NAD 10
BV2	NAD 20	NAD 20	NAD 20
BV3	NAD 50	NAD 50	NAD 50
BV4	NAD 100	NAD 100	NAD 100
BV5	NAD 200	NAD 200	NAD 200