

# U72 Option Switch Settings (Pulse/MDB/RS232 002)

Supported bill MYR 1, 5, 10, 20, 50, 100 6 Bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject MYR 1 & 5	ON											
★ Accept MYR 1 & 5	OFF											
★ Reject MYR 10 & 20		ON										
★ Accept MYR 10 & 20		OFF										
★ Reject MYR 50 & 100			ON									
★ Accept MYR 50 & 100			OFF									
★ High Acceptance				ON								
★ High Security				OFF								
Enable, if fishing, BA doesn't work anymore					ON							
★ Disable, BA works normally					OFF							
Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★ Harness Disable							ON					
★ Harness Enable							OFF					
★ Inhibit Active HIGH								ON				
★ Inhibit Active LOW								OFF				
★ Power On Stacker									ON			
★ Power On Reject									OFF			
★ Slow Output Pulse	Lo 50 ms									ON		
	Hi 300 ms											
★ Fast Output Pulse	Lo 50 ms									OFF		
	Hi 100 ms											
★ Reserved											ON	
★ Reserved											OFF	
★ Reserved												ON
★ Reserved												OFF

★Manufacture setting

Note : Please reset the bill acceptor after any changes on Dip switch.

# U72 MYR6(Pulse/MDB/RS232 002)

## DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal High	ON			
	Credit-Pulse Normal Low	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / MYR 1			OFF	OFF
	2 pulse / MYR 1			OFF	ON
	4 pulse / MYR 1			ON	OFF
	20 pulse / MYR 1			ON	ON

★Manufacture setting

## DIP SWITCHES SETTING : 2(RS232 002)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB			OFF	OFF
★	RS232 002			OFF	ON
	Reserved			ON	OFF
	Reserved			ON	ON

★Manufacture setting

## DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB			OFF	OFF
	RS232 002			OFF	ON
	Reserved			ON	OFF
	Reserved			ON	ON

★Manufacture setting

Note :(1) Please reset the bill acceptor after any changes on Dip switch.

(2)Please open the panel of front, and can see the DIP switch.

## Currency Assign Data

Interface Bill value	Pulse	MDB	RS232 002
BV1	MYR 1	MYR 1	MYR 1
BV2	MYR 5	MYR 5	MYR 5
BV3	MYR 10	MYR 10	MYR 10
BV4	MYR 20	MYR 20	MYR 20
BV5	MYR 50	MYR 50	MYR 50
BV6	MYR 100	MYR 100	MYR 100